

Henry K. Nahra, Ph.D.
Mohammad Mojibul Hasan, Ph.D.

TWO PHASE FLOWS AND HEAT TRANSFER

TWO PHASE FLOWS AND PHASE TRANSITION



References

- ✖ 1. Mudawar I., "Two-Phase Flow and Heat Transfer", NASA-GRC, December, 2013, February, 2014
- ✖ 2. Collier J.G and Thome J.R, "Convective Boiling and Condensation", 3rd Edition, Oxford University Press Inc., NY, 2001
- ✖ 3. Fox, Pritchard and McDonald, "Introduction to Fluid Mechanics", 7th Edition.
- ✖ 4. Holman, "Heat Transfer", Fourth Edition, McGraw-Hill Inc., 1976



OUTLINE

- ✖ In this short course, we will address the following topics
 - + Two-phase flows hydrodynamics and pressure drop of evaporating and condensing flows
 - ✖ Homogeneous Equilibrium Model
 - ✖ Separated Flow Model
 - + Two-phase flows heat transfer and heat transfer coefficients predictions in evaporating and condensing flow
 - ✖ Homogeneous Equilibrium Model
 - ✖ Separated Flow Model
- ✖ This short course focuses on predictive methods for calculation of two phase pressure drop and heat transfer

HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS



✖ One Dimensional Two Phase Flow


+ Definitions of Two-Phase Flow Parameters

✖ Area

One Dimensional Two-phase Flow

Area A_f, A_g [m^2]

$$A = A_f + A_g$$



✖ Flow Rates

Mass flow rate

W_g, W_f [kg/s]

$$W = W_g + W_f$$

Mass Velocity

$$G = \frac{W}{A} \quad kg/m^2.s$$

Volumetric Flow rate.

Q_g, Q_f

$$Q = Q_g + Q_f$$



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

+ Liquid and Gas Phase Velocity

Phase velocity

u_g, u_f [m/s]

$$u_g = \frac{Q_g}{A_g} \quad ; \quad u_f = \frac{Q_f}{A_f} = \frac{W_f}{\rho_f \cdot A_f}$$

$$= \frac{Q_g \rho_g}{\rho_g \cdot A_g} = \frac{W_g}{\rho_g \cdot A_g}$$

Recall

$$W[\text{kg/s}] = Q \left[\frac{\text{m}^3}{\text{s}} \right] \times \rho \left[\frac{\text{kg}}{\text{m}^3} \right]$$

+ Volume and Area Based Void Fraction

Void fraction - Volume based

$$\alpha_v = \frac{V_g}{V_f + V_g} =$$

Void fraction - Area Based

$$\alpha = \frac{A_g}{A_g + A_f} = A_g / A$$

Volumetric flow fraction β .

$$\beta = \frac{Q_g}{Q} = \frac{A_g u_{g1} / u_{g1}}{A_g u_{g1} / u_{g1} + A_f u_{f1} / u_{g1}} = \frac{A_g}{A_g + A_f \left(\frac{1}{S} \right)} \quad S \equiv u_g / u_f \equiv \text{slip ratio}$$

For most applications $S > 1$

For $S=1 \rightarrow$ Homogeneous flow $\Rightarrow \beta = \alpha$ Area-Based



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

+ Flow Quality

+

Flow Quality

$$x = \frac{W_g}{W_g + W_f} = \frac{\cancel{P_g A_g u_g} / \cancel{P_g u_g A_g}}{\cancel{P_g A_g u_g} + \frac{P_f u_f A_f}{P_g A_g u_g}} = \frac{1}{1 + \frac{P_f}{P_g} \frac{A_f}{A_g} \frac{u_f}{u_g}}$$

$$= \frac{1}{1 + \frac{P_f}{P_g} \frac{A_f}{A_g} \frac{1}{S}} \quad \frac{A_f}{A_g} = \frac{A - A_g}{A_g} = \frac{A}{A_g} - 1 = \frac{1}{\alpha} - 1 = \left(\frac{1-\alpha}{\alpha}\right)$$

$$\Rightarrow x = \frac{1}{1 + \frac{P_f}{P_g} \cdot \left(\frac{1-\alpha}{\alpha}\right) \cdot \frac{1}{S}}$$

$$x = \frac{1}{1 + \frac{P_f}{P_g} \frac{A_f}{A_g} \frac{u_f}{u_g}} \Rightarrow x + x \frac{P_f}{P_g} \cdot \frac{A_f}{A_g} \frac{u_f}{u_g} = 1$$

$$\frac{A_f}{A_g} = \frac{1-x}{x \frac{P_f}{P_g} \frac{u_f}{u_g}} = \frac{1}{\alpha} - 1 \Rightarrow \frac{1}{\alpha} = 1 + \frac{1-x}{x \frac{P_f}{P_g} \frac{u_f}{u_g}}$$

$$\Rightarrow \alpha = \frac{1}{1 + \left(\frac{1-x}{x}\right) \frac{P_g}{P_f} S} \Rightarrow \text{For a small } x \Rightarrow \text{Large } \alpha$$




HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

+ Calculation of Void Fraction from Flow Quality

$$\alpha[x, \rho_f, \rho_g, S] := \frac{1}{1 + \left(\frac{1-x}{x}\right) \frac{\rho_g}{\rho_f} S}$$

```
Plot[{ $\alpha[x, 1.6, .013, 1]$ ,  $\alpha[x, 1.6, .05, 1]$ ,  $\alpha[x, 1.6, .013, 10]$ ,  $\alpha[x, 1, .001, 1]$ ,  $x$ }, { $x, 0, 1$ }, Frame -> True, PlotRange -> {{0, 1}, {0, 1}},  
FrameLabel -> {"x", " $\alpha$ ", " $\rho_f/\rho_g=123,32,1000$  &  $S=1, \rho_f/\rho_g=123$  &  $S=10$ ", ""}, LabelStyle -> {FontSize -> 18}, AspectRatio -> .7, GridLines -> Automatic]
```



$$\alpha = \frac{1}{1 + \left(\frac{1-x}{x}\right) \frac{\rho_g}{\rho_f} S}$$

Void fraction as a function of quality for different density ratios and slip factors



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

+ Average Density and Specific Volume of Mixture

Mixture Density $\bar{\rho}$

$$\bar{\rho} = \frac{A_g}{A} \rho_g + \frac{A_f}{A} \rho_f = \alpha \rho_g + (1-\alpha) \rho_f \quad \text{But } \alpha = \left(1 + \rho_g/\rho_f \left(\frac{1-x}{x}\right)\right)^{-1} \text{ for } S=1$$

$$\frac{1}{\bar{\rho}} = \frac{1}{\alpha \rho_g + (1-\alpha) \rho_f} \quad \alpha = \frac{1 \cdot x \cdot \rho_f}{\rho_f x + \rho_g (1-x)}$$

$$\begin{aligned} \frac{1}{\bar{\rho}} &= \frac{1}{\frac{x \rho_f \cdot \rho_g}{x \rho_f + \rho_g (1-x)} + \left(1 - \frac{x \rho_f}{x \rho_f + \rho_g (1-x)}\right) \cdot \rho_f} \\ &= \frac{1}{\frac{x \rho_f \rho_g}{x \rho_f + \rho_g (1-x)} + \rho_f \frac{(x \rho_f + \rho_g (1-x) - x \rho_f)}{x \rho_f + \rho_g (1-x)}} \\ &= \frac{x \rho_f + \rho_g (1-x)}{x \rho_f \rho_g + x \rho_f^2 + \rho_f \rho_g (1-x) - x \rho_f^2} \\ &= \frac{x \rho_f + \rho_g (1-x)}{x \rho_f \rho_g + \rho_f \rho_g (1-x)} = \frac{x \rho_f + \rho_g (1-x)}{\rho_f \rho_g} = \frac{x}{\rho_g} + \frac{1-x}{\rho_f} \\ &= x v_g + (1-x) v_f = \bar{v} \end{aligned}$$

$\bar{v} = (1-x)v_f + xv_g = 1/\bar{\rho}$




HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

+ Calculation of Average Density of Mixture

$$\rho_{avg}[x, \rho_f, \rho_g] := \frac{1}{x / \rho_g + (1 - x) / \rho_f};$$

```
LogPlot[{  $\rho_{avg}[x, 1., .001]$ ,  $\rho_{avg}[x, 1.6, .013]$  }, {x, 0, 1}, Frame -> True, PlotRange -> {{0.0001, 1}, {0.0001, 1.2}},  
FrameLabel -> {"x", " $\bar{\rho}$  [g/cm3]", " $\rho_f/\rho_g=1000$ -Blue, 123-Orange", ""}, LabelStyle -> (FontSize -> 24), AspectRatio -> .7, GridLines -> Automatic]
```





HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

- ✖ Two Phase Flow Regime in a Heated Tube
- ✖ Let's define the flow and thermodynamic quality

$$\dot{Q}_f = \text{constant}$$

$$q'' \equiv \text{constant}$$

Flow quality

$$x = \frac{\rho_g u_g A_g}{\rho_g u_g A_g + \rho_f u_f A_f} = \frac{w_g}{w}$$

Thermodynamic equilibrium quality

"Mixing Cup" Quality

$$x_e = \frac{h - h_f}{h_{fg}}$$

Mixture enthalpy

Attributes of thermodynamic quality

If $h < h_f \Rightarrow x_e < 0$
Subcooled Liquid

If $h > h_g \Rightarrow x_e > 1$
Superheated Vapor



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

Homogeneous Two-Phase Equilibrium Model



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

✗ Homogeneous Two-Phase Equilibrium Model

For the Homogeneous Equilibrium flow

$$S=1 \quad \Rightarrow \quad x = x_e \quad \text{for } 0 \leq x_e \leq 1$$

$x \neq x_e$ because of the superheated liquid layer near the wall

Homogeneous Two Phase Flow Model Applicability to Bubble and Mist Flow

Assumptions

- Uniform Velocity $u_g = u_f = u \quad \Rightarrow S=1$
- Uniform pressure $p_g = p_f = p$

Homogenous equilibrium Model

$$T_g = T_f = T_{sat}|_{p=\text{local pressure}} \quad \Rightarrow \quad x_e = x \quad 0 \leq x_e \leq 1$$



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

✕ Conservation Laws and the Laws of Thermodynamics

Conservation of Mass

$$\left. \frac{dM}{dt} \right|_{System} = 0$$

$$M_{System} = \int_{M_{System}} dm = \int_{V_{System}} \rho dv$$

Newton's Second Law

$$\left. \frac{d\vec{P}}{dt} \right|_{System} = \sum \vec{F}$$

$$\vec{P}_{System} = \int_{M_{System}} \vec{V} dm = \int_{Vol_{System}} \vec{V} \rho dv$$

The First and Second Law of Thermodynamics

$$\left. \frac{dE}{dt} \right|_{System} = \dot{Q} - \dot{W}$$

$$E_{System} = \int_{M_{System}} e dm = \int_{V_{System}} e \rho dv$$

$$e = u + \frac{V^2}{2} + gz$$

$$\left. \frac{dS}{dt} \right|_{System} \geq \frac{1}{T} \dot{Q}$$

$$S_{System} = \int_{M_{System}} s dm = \int_{V_{System}} s \rho dv$$



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

- ✘ Develop a Control Volume Formulation from system rate relations
- ✘ For any extensive property N representing mass, momentum, energy, entropy or angular momentum,

+ Then, for any extensive property

$$\begin{aligned}
 N = M, & \quad \text{then } \eta = 1 \\
 N = \vec{P}, & \quad \text{then } \eta = \vec{V} \\
 N = \vec{H}, & \quad \text{then } \eta = \vec{r} \times \vec{V} \\
 N = E, & \quad \text{then } \eta = e \\
 N = S, & \quad \text{then } \eta = s
 \end{aligned}$$


+ The following is true...

$$N_{\text{system}} = \int_{M(\text{system})} \eta \, dm = \int_{\forall(\text{system})} \eta \, \rho \, d\forall$$



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

- ✖ Select an arbitrary piece of fluid flowing at $t=t_0$
- ✖ Die the piece in blue and take the shape of this piece as the control volume which is fixed in space




- ✖ After Δt , the system has moved to another point in space yet the control volume is still fixed in space.
- ✖ Examining the control volume/system pair geometry at t_0 and $t_0 + \Delta t$ will result in the control volume description



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

- At $t=t_0$, the system is in the control volume.
- At $t=t_0 + \Delta t$, part of the system is in the control volume
- Three regions result. They are labeled as regions I, II, III



$$\left. \frac{dN}{dt} \right]_{System} = \lim_{\Delta t \rightarrow 0} \frac{N_S]_{t_0 + \Delta t} - N_S]_{t_0}}{\Delta t} \longrightarrow N_S)_{t_0} = (N_{CV})_{t_0} \quad +$$

$$N_S)_{t_0 + \Delta t} = (N_{II} + N_{III})_{t_0 + \Delta t} = (N_{CV} - N_I + N_{III})_{t_0 + \Delta t}$$

$$\left. \frac{dN}{dt} \right)_s = \lim_{\Delta t \rightarrow 0} \frac{(N_{CV} - N_I + N_{III})_{t_0 + \Delta t} - N_{CV})_{t_0}}{\Delta t}$$



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

- ✧ This yields

$$\left(\frac{dN}{dt} \right)_{\text{system}} = \frac{\partial}{\partial t} \int_{\text{CV}} \eta \rho dV + \int_{\text{CS}_I} \eta \rho \vec{V} \cdot d\vec{A} + \int_{\text{CS}_{III}} \eta \rho \vec{V} \cdot d\vec{A}$$

- ✧ Since CS_I and CS_{III} form the Control Volume Surface, the last two surface integrals combine into one integral namely,

$$\left(\frac{dN}{dt} \right)_{\text{system}} = \frac{\partial}{\partial t} \int_{\text{CV}} \eta \rho dV + \int_{\text{CS}} \eta \rho \vec{V} \cdot d\vec{A}$$

- ✧ **Reynolds Transport Theorem** relates the rate of change of the extensive property N of the system with the variation of the property associated with the control volume

HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS



✕ Physical Interpretation

$$\left. \frac{dN}{dt} \right)_{\text{system}}$$

is the rate of change of the system extensive property N . For example, if $N = \vec{P}$, we obtain the rate of change of momentum.

$$\frac{\partial}{\partial t} \int_{\text{CV}} \eta \rho dV$$

is the rate of change of the amount of property N in the control volume. The term $\int_{\text{CV}} \eta \rho dV$ computes the instantaneous value of N in the control volume ($\int_{\text{CV}} \rho dV$ is the instantaneous mass in the control volume). For example, if $N = \vec{P}$, then $\eta = \vec{V}$ and $\int_{\text{CV}} \vec{V} \rho dV$ computes the instantaneous amount of momentum in the control volume.

$$\int_{\text{CS}} \eta \rho \vec{V} \cdot d\vec{A}$$

is the rate at which property N is exiting the surface of the control volume. The term $\rho \vec{V} \cdot d\vec{A}$ computes the rate of mass transfer leaving across control surface area element $d\vec{A}$; multiplying by η computes the rate of flux of property N across the element; and integrating therefore computes the net flux of N out of the control volume. For example, if $N = \vec{P}$, then $\eta = \vec{V}$ and $\int_{\text{CS}} \vec{V} \rho \vec{V} \cdot d\vec{A}$ computes the net flux of momentum out of the control volume.



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

✕ One Dimensional Conservation of Mass, Momentum and Energy

+ Conservation of Mass

$$\left. \frac{dM}{dt} \right|_{\text{System}} = 0$$

$$M_{\text{System}} = \int_{M_{\text{System}}} dm = \int_{V_{\text{System}}} \rho dv$$

Conservation of Mass

Transport theorem


$$\frac{\partial}{\partial t} \int_V \bar{\rho} dv + \int_S \bar{\rho} \vec{u}_r \cdot d\vec{S} = 0$$

storage rate

Mass out
- Mass in

$$\frac{\partial}{\partial t} (\bar{\rho} A \Delta z) + W + \frac{\partial W}{\partial z} \Delta z - W = 0$$

$$\frac{\partial}{\partial t} (\bar{\rho} A) + \frac{\partial W}{\partial z} = 0$$



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS



+ Conservation of Momentum

$$\left. \frac{d\vec{P}}{dt} \right|_{\text{System}} = \sum \vec{F}$$

$$\vec{P}_{\text{System}} = \int_{M_{\text{System}}} \vec{V} dm = \int_{\text{Vol}_{\text{System}}} \vec{V} \rho dv$$


Momentum Along z direction. $\bar{\rho}u$

$$\frac{\partial}{\partial t} \int_V \bar{\rho}u dv + \int_S (\bar{\rho}u) u_{\text{r.o.}} d\vec{S} = \sum_i F_z$$


storage

Mom. out - Mom. in = Net force.

Shear and Body forces



Pressure



$$\frac{\partial}{\partial t}(\bar{\rho}uA) + \frac{\partial}{\partial z}(\bar{\rho}u^2A) = -A \frac{\partial p}{\partial z} - \tau_f P_f - \bar{\rho}gA \sin \theta$$



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

+ Conservation of Energy

$$\left. \frac{dE}{dt} \right|_{\text{System}} = \dot{Q} - \dot{W}$$

$$E_{\text{System}} = \int_{M_{\text{System}}} e dm = \int_{V_{\text{System}}} e \rho dv$$

$$e = u + \frac{V^2}{2} + gz$$

$$\frac{\partial}{\partial t} (\bar{\rho} h^0 A) + \frac{\partial}{\partial z} (\bar{\rho} h^0 u A) = q'' P_H + q''' A + \frac{\partial}{\partial t} (pA) \quad \text{where } h^0 = e^0 + pv$$

Conservation of energy. — $e^0 = e + \frac{u^2}{2} + gz \sin \theta$

$$\frac{J}{kg} = \frac{kg \frac{m}{s^2} \times m}{kg} \rightarrow \frac{m^2}{s^2} \quad \checkmark$$

Internal energy
storage rate

+ Internal Energy
out — In

= Rate of Heat
transferred
to CV.

— Rate of work
done by
CV.



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

+ Assumptions

Steady state $\frac{\partial}{\partial t} = 0$; No chem. reaction $\dot{q}'' = 0$
 Tubular geometry $A = \text{const.}$

Neglect changes in kinetic and potential energy
 Assume constant properties for individual phases

$$\frac{\partial}{\partial t}(\bar{\rho}A) + \frac{\partial W}{\partial z} = 0 \quad \Rightarrow \quad W \equiv \text{const} = \bar{\rho}uA = G A$$

Const. Area $\Rightarrow G = \text{constant}$

Momentum

$$\frac{\partial}{\partial t}(\bar{\rho}uA) + \frac{\partial}{\partial z}(\bar{\rho}u^2A) = -A \frac{\partial p}{\partial z} - \mathcal{L}_F P_F - \bar{\rho}gA \sin \theta ; \bar{\rho}uA = G \cdot A = W$$

$$W \frac{du}{dz} = -A \frac{dp}{dz} - \mathcal{L}_F P_F - \bar{\rho}A g \sin \theta$$

Energy

$$\frac{\partial}{\partial t}(\bar{\rho}h^0A) + \frac{\partial}{\partial z}(\bar{\rho}h^0uA) = \dot{q}'' P_H + \dot{q}''' A + \frac{\partial}{\partial t}(\bar{\rho}A) \rightarrow 0$$

$$\Rightarrow W \frac{dh}{dz} = P_H \dot{q}''$$



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

Solution

- + Solve the conservation of mass and energy first to obtain the thermodynamic quality

$$\frac{\partial}{\partial t}(\bar{\rho}A) + \frac{\partial W}{\partial z} = 0$$



$$\frac{\partial}{\partial t}(\bar{\rho}h^0 A) + \frac{\partial}{\partial z}(\bar{\rho}h^0 uA) = q'' P_H + q''' A + \frac{\partial}{\partial t}(pA)$$



x



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

Solution

- + After quality is solved for, solve the momentum equation to obtain the pressure drop

 x 

$$\frac{\partial}{\partial t}(\bar{\rho}uA) + \frac{\partial}{\partial z}(\bar{\rho}u^2A) = -A\frac{\partial P}{\partial z} + -\tau_f P_f - \bar{\rho}gA\sin(\theta)$$

 ΔP

HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS



✖ Solution

Mass + Energy \rightarrow $x \rightarrow$ Momentum $\rightarrow \Delta p$

$$\frac{dh}{dz} = q'' \frac{P_H}{W}$$

$$h = h_f + x_e h_{fg}$$

$$h_{fg} \frac{dx_e}{dz} = q'' \frac{P_H}{W} \Rightarrow dx_e = \frac{q'' P_H}{W h_{fg}} dz$$

$$\Rightarrow x_e = x_{e,i} + \frac{P_H}{W h_{fg}} \int_0^z q'' dz$$

What is $x_{e,i}$ $x_{e,i}$ Thermodynamic Equilibrium quality at inlet

$$x_{e,i} = \frac{h_i - h_f}{h_{fg}} = \frac{-(h_f - h_i)}{h_{fg}} = \Delta h_{sub,i}$$

$$= - \frac{C_{p,f} (T_{sat} - T_i)}{h_{fg}} = - \frac{C_{p,f} \Delta T_{sub,i}}{h_{fg}}$$

$$\Rightarrow x_e = - \frac{C_{p,f} \Delta T_{sub}}{h_{fg}} + \frac{P_H}{W h_{fg}} \int_0^z q'' dz$$



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

+ Quality and thermodynamic quality

$$h_i = h_f \Rightarrow x_{e,i} = 0$$

$$h_f < h_i < h_g \Rightarrow 0 < x_{e,i} < 1$$

$$h_i = h_g \Rightarrow x_{e,i} = 1$$

$$h_i > h_g \Rightarrow x_{e,i} > 1$$

$$x_{e,i} = \frac{h_i - h_f}{h_{fg}} = \frac{h_g - h_f + h_i - h_g}{h_{fg}} = \frac{h_{fg} + C_{p,g}(T_i - T_{sat})}{h_{fg}} \quad \text{For superheated region}$$

$$= 1 + C_{p,g} \frac{(T_i - T_{sat})}{h_{fg}}$$

$$x = \begin{cases} 0 & x_e < 0 \\ x_e & 0 \leq x_e \leq 1 \\ 1 & x_e > 1 \end{cases}$$



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

For a uniformly heated circular tube, find the axial location z at which

$$x_e = 0 \text{ and } x_e = 1$$


$$T_i < 100^\circ\text{C}.$$

$$x_e(z) = -\frac{C_{p,f} \Delta T_{\text{sub},i}}{h_{fg}}$$

$$+ \frac{P_H}{W h_{fg}} \int_0^z q'' dz$$

$$= -\frac{C_{p,f} \Delta T_{\text{sub}}}{h_{fg}} + \frac{\pi D q'' z}{W h_{fg}}$$


$$x_e = 0 \Rightarrow z|_{x_e=0} = \frac{\frac{C_{p,f} \cdot \Delta T_{\text{sub}}}{h_{fg}}}{\frac{\pi D q''}{W h_{fg}}} = \frac{W C_{p,f} \Delta T_{\text{sub}}}{\pi D q''}$$





HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

- + Uniformly heated Circular Tube
- + Finding $x(z)$, $\alpha(z)$, $u(z)$

 Homogeneous Two-Phase Flow Model – Steady State Solutions			
Region	x	α	u
Subcooled $z < z _{x_e=0}$	0	0	$\frac{G}{\rho_f}$
Saturated $z _{x_e=0} < z < z _{x_e=1}$	x_e	$\frac{1}{1 + \frac{\rho_g}{\rho_f} \left(\frac{1 - x_e}{x_e} \right)}$	$G [x_e v_g + (1 - x_e) v_f]$
Superheated $z > z _{x_e=1}$	1	1	$\frac{G}{\rho_g}$



October 2013 Short Course
NASA Glenn Research Center

Course: Two-Phase Flow

Prof. Issam Mudawar



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

Example Problem Water Upward Flow in a Heated Pipe...

PURDUE
UNIVERSITY

Numerical Example I: Determination of Pressure Drop using HEM with Constant Two-Phase Friction Factor for Heated Vertical Upflow with Saturated Inlet

Saturated water ($x_e = 0$) at mass velocity $G = 250 \text{ kg/m}^2\cdot\text{s}$ and inlet pressure of $p_i = 5 \text{ bar}$ enters a vertical circular tube of diameter $D = 1 \text{ cm}$ and length $L = 100 \text{ cm}$, where it is subjected to a constant heat flux $q'' = 10^6 \text{ W/m}^2$. Neglecting any kinetic or potential energy effects and assuming constant thermophysical properties, use the Homogeneous Equilibrium Model (HEM) with a constant two-phase friction factor $f_{TP} = 0.003$ to determine the following:


(a) $x_e(z)$, $x_{e,L}$

(b) Δp_F

(c) Δp_A

(d) Δp_G

(e) Δp



October 2013 Short Course
NASA Glenn Research Center

Course: Two-Phase Flow

Prof. Issam Mudawar



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

- + Finding $x_e[z]$ and the z location where the thermodynamic quality $x_e = 0$ and $x_e = 1$
- + Finding $x_e[L]$
- + Finding $x[z]$ based on $x_e[z]$, and finding $x'[z]$

$$x_e[z] := -\frac{C_{pf} \Delta T_{sub}}{h_{fg}} + \frac{\pi DD q}{W h_{fg}} z$$

$$z_{xe0} = \frac{W C_{pf} \Delta T_{sub}}{\pi DD q};$$

```
Print["z | x_e=0 is ", zxe0]
```

$z | x_e=0$ is 0.

```
xe[1]; Print["x_e[L]=", xe[L]]
```

$x_e[L] = 0.759013$


$$z_{xe1} = \frac{h_{fg} W}{\pi DD q} + \frac{C_{pf} \Delta T_{sub} W}{\pi DD q};$$

```
If[zxe1 > L, zxe1 = L, zxe1];
```

```
x[z_] := Piecewise[{{0, z < zxe0}, {xe[z], z > zxe0 && z < zxe1}, {Min[xe[L], 1], z > zxe1}}]
```

```
xp[z_] := x'[z]
```

```
Plot[x[z], {z, 0, L}, Frame -> True, FrameLabel -> {"z [m]", "Quality x"}, GridLines -> Automatic, LabelStyle -> {FontSize -> 16}]
```



$$x = \begin{cases} 0 & x_e < 0 \\ x_e & 0 \leq x_e \leq 1 \\ 1 & x_e > 1 \end{cases}$$

```
p = 5 (*bar*);
Cpf = 4312 (*J/kg.K*);
hfg = 2.108 * 10^6 (*J/kg*);
vf = .0011 (*m^3/kg*);
vg = .3748 (*m^3/kg*);
mf = 180.1 * 10^-6 (*kg/m.s*); mu = 14.06 * 10^-6 (*kg/m.s*);
q = 1.0 * 10^6 (*W/m^2*); DTsub = 0 (*C*);
g = 9.8 (*m.s^-2*);
theta = 90/180 * pi;
DD = .01 (*m*);
L = 1 (*m*);
G = 250 (*kg/m^2.s*);
W = G * pi * (DD^2/4);
A = (pi * DD^2/4) (*m^2*);
peri = pi * DD (*m*); DF = (4 * A/peri) (*m*);
vfg = vg - vf;
ReyNum = G * DF / mf;
```



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

✖ Pressure Drop in Two Phase Homogeneous Equilibrium Model

✖ Solving for $-dP/dz$



$$W \frac{du}{dz} = -A \frac{dp}{dz} - \mathcal{F}_F P_F - \bar{\rho} g \sin \theta$$

From Conservation of Momentum

$$-\frac{dp}{dz} = \underbrace{\frac{\mathcal{F}_F P_F}{A}}_{\text{Frictional } -\frac{dp}{dz}|_F} + \underbrace{\frac{W}{A} \frac{du}{dz}}_{\text{Acceleration } -\frac{dp}{dz}|_A} + \underbrace{\bar{\rho} g \sin \theta}_{\text{Gravitational } -\frac{dp}{dz}|_G}$$



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

+ Frictional Pressure Drop

- ✗ Follow along the line of a single fluid
- ✗ f_{TP} stands for the friction coefficient for two phase

$$-\frac{dp}{dz} \Big|_F = \tau_f \frac{P_F}{A} \quad \text{Given} \quad D_H = \frac{4A}{P} \quad P = \frac{4A}{D_H}$$

$$\Rightarrow -\frac{dp}{dz} = \frac{\tau_f 4A}{D_H A} = \frac{4}{D_F} \left(f_{TF} \frac{1}{2} \bar{\rho} u^2 \right)$$

$$\Rightarrow -\frac{dp}{dz} = \frac{2}{D_F} f_{TF} G^2 (\nu_f + x \nu_{fg})$$

+ Acceleration Pressure Drop

$$-\frac{dp}{dz} \Big|_A = W \frac{du}{dz} = \frac{W}{A} \frac{d}{dz} \left(\frac{W}{\bar{\rho} A} \right) = \frac{W^2}{A} \frac{d}{dz} \left(\frac{1}{\bar{\rho}} \right)$$

$$= \frac{W^2}{A} \frac{d}{dz} (\nu_f + x \nu_{fg}) = \frac{W^2}{A} \nu_{fg} \frac{dx}{dz}$$

+ Pressure Drop due to Gravity

$$-\frac{dp}{dz} \Big|_G = \bar{\rho} g \sin \theta = \frac{\rho g \sin \theta}{(\nu_f + x \nu_{fg})}$$



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

+ Observations

- Pressure drop increases drastically with vapor formation
- For Adiabatic Flows (meaning no phase transition, $dx/dz=0$ which implies that - $dP/dz|_A=0$
- For horizontal flows, gravity induced pressure drop
➡ $-dP/dz|_G=0$

Adiabatic horizontal flows are used to determine the frictional gradient from measurement of the total pressure gradient



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

+ Two-phase Friction Factor

$$-\frac{dP}{dz} / F = \frac{2}{D_F} f_{TP} G^2 x_f \left(1 + x \frac{v_{fg}}{v_f} \right)$$

By Analogy with single ϕ flow

$$f_{TP} = \frac{c}{\left(\frac{G D_F}{\mu} \right)^n} = \frac{c}{\left(\frac{G D_F}{\mu_f} \right)^n} \left(\frac{\mu}{\mu_f} \right)^n$$

$f_{fo} \leftarrow$ Liquid only

$$\Rightarrow f_{TP} = f_{fo} \left(\frac{\mu}{\mu_f} \right)^n \rightarrow \text{Mixture viscosity}$$

$$-\frac{dP}{dz} / F = \frac{2}{D_F} G^2 x_f \frac{f_{TP}}{f_{fo}} \left(1 + x \frac{v_{fg}}{v_f} \right)$$

$$= \underbrace{-\left(\frac{dP}{dz} \right)_{F_{fo}}}_{\left(\frac{\mu}{\mu_0} \right)^n} \left(1 + x \frac{v_{fg}}{v_f} \right)$$

$$\Rightarrow -\left(\frac{dP}{dz} \right)_F = -\left(\frac{dP}{dz} \right)_{F_{fo}} \phi_{fo}^2 \leftarrow \text{Two phase friction Multiplier}$$

f_{TP}

Two phase
friction factor



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

+ Pressure Drop Calculations/Constant Two-Phase Friction Factor

Use constant f_{TP}

$$-\frac{dp}{dz} = \frac{2}{D_F} f_{TP} G^2 v_f \left(1 + x \frac{v_g}{v_f} \right)$$

$$.0029 < f_{TP} < .005$$

+ Pressure Drop Calculations/Using Two-Phase Viscosity Models

Using Viscosity Models

$$-\left(\frac{dp}{dz}\right)_F = \left\{ \frac{2}{D_F} f_{fo} G^2 v_f \right\} \phi_{fo}^2$$

$$f_{fo} = \left[\frac{c}{G D_F \mu_f} \right]^n \quad ; \quad \phi_{fo}^2 = \left(\frac{\bar{\mu}}{\mu_f} \right)^n \left(1 + x \frac{v_g}{v_f} \right)$$

Mc Adams (1942) $\frac{1}{\bar{\mu}} = \frac{x}{\mu_g} + \frac{1-x}{\mu_f}$

Cicciitti et al (1960) $\bar{\mu} = x \mu_g + (1-x) \mu_f$

Duckler (1964) $\bar{\mu} = \frac{x v_g \mu_g + (1-x) v_f \mu_f}{x v_g + (1-x) v_f}$



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS




Two-Phase Viscosity Models

```

 $\mu_{MA}[z\_]$  :=  $\frac{\mu_g \mu_f}{x[z] \mu_f + (1 - x[z]) \mu_g}$  (*kg/m.s*); "McAdams";
 $\mu_C[z\_]$  :=  $x[z] \mu_g + (1 - x[z]) \mu_f$  (*kg/m.s*); "Ciccitti et al.";
 $\mu_D[z\_]$  :=  $\frac{x[z] v_g \mu_g + (1 - x[z]) v_f \mu_f}{x[z] v_g + (1 - x[z]) v_f}$  (*kg/m.s*); "Duckler";
Plot[{ $\mu_{MA}[z]$ ,  $\mu_C[z]$ ,  $\mu_D[z]$ }, {z, 0, 1}, Frame -> True, FrameLabel -> {"z [m]", " $\mu_{TP}$  [kg/m.s]"}, LabelStyle -> {FontSize -> 18},
FrameTicks -> Automatic, FrameTicksStyle -> Black, GridLines -> Automatic, GridLinesStyle -> Directive[Dotted, Gray]]

```



```

coef = If[ReyNum < 2300, {c = 16, n = 1}, If[ $4 \times 10^3 < \text{ReyNum} < 2 \times 10^4$ , {c = .079, n = .25}],
If[ReyNum >  $2 \times 10^4$ , {c = .046, n = .2}]]

```



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

✖ Total Two Phase Pressure Drop

$$\begin{aligned}
 -\left(\frac{dp}{dz}\right)_{\text{Total}} &= -\left(\frac{dp}{dz}\right)_F + -\left(\frac{dp}{dz}\right)_A + -\left(\frac{dp}{dz}\right)_G \\
 &= \frac{2}{D_F} \int_{TP} G^2 v_f \left(1 + x \frac{v_{fg}}{v_f}\right) \\
 &\quad + G^2 v_{fg} \frac{dx}{dz} \\
 &\quad + \frac{g \sin \theta}{v_f \left(1 + x \frac{v_{fg}}{v_f}\right)}
 \end{aligned}$$

✖ Total Pressure Drop

$$\begin{aligned}
 \Delta p(z) &= \Delta p_{\text{liquid phase}} + \left[\int_{z|x_e=0}^z \left\{ \frac{2}{D_F} c \left(\frac{G D_F}{\mu_f} \right)^{-n} \left(\frac{\mu(\xi)}{\mu_f} \right)^n G^2 v_f \left(1 + x(\xi) \left(\frac{v_{fg}}{v_f} \right) \right) + G^2 v_{fg} \left(\frac{dx(\xi)}{dz} \right) + \frac{g \sin(\theta)}{v_f \left(1 + x(\xi) \left(\frac{v_{fg}}{v_f} \right) \right)} \right\} d\xi \right] + \\
 &\quad \Delta p_{\text{Vapor phase}}
 \end{aligned}$$



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS


Example Problem



Numerical Example 1: Determination of Pressure Drop using HEM with Constant Two-Phase Friction Factor for Heated Vertical Upflow with Saturated Inlet

Saturated water ($x_e = 0$) at mass velocity $G = 250 \text{ kg/m}^2\cdot\text{s}$ and inlet pressure of $p_i = 5 \text{ bar}$ enters a vertical circular tube of diameter $D = 1 \text{ cm}$ and length $L = 100 \text{ cm}$, where it is subjected to a constant heat flux $q'' = 10^6 \text{ W/m}^2$. Neglecting any kinetic or potential energy effects and assuming constant thermophysical properties, use the Homogeneous Equilibrium Model (HEM) with a constant two-phase friction factor $f_{TP} = 0.003$ to determine the following:

- (a) $x_e(z), x_{e,L}$
- (b) Δp_F
- (c) Δp_A
- (d) Δp_G
- (e) Δp



October 2013 Short Course
NASA Glenn Research Center

Course: Two-Phase Flow

Prof. Issam Mudawar



HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

Forming the Pressure Gradients Integrands

$$\begin{aligned} \text{intMA}[z_]&:= \frac{2}{DF} c \left(\frac{G DF}{\mu f} \right)^{-n} \left(\frac{\mu MA[z]}{\mu f} \right)^n G^2 vf \left(1 + \frac{x[z] vfg}{vf} \right) + G^2 vfg xp[z] + \frac{g \sin[\theta]}{vf (1 + x[z] vfg / vf)} ; \\ \text{intC}[z_]&:= \frac{2}{DF} c \left(\frac{G DF}{\mu f} \right)^{-n} \left(\frac{\mu C[z]}{\mu f} \right)^n G^2 vf \left(1 + \frac{x[z] vfg}{vf} \right) + G^2 vfg xp[z] + \frac{g \sin[\theta]}{vf (1 + x[z] vfg / vf)} \\ \text{intD}[z_]&:= \frac{2}{DF} c \left(\frac{G DF}{\mu f} \right)^{-n} \left(\frac{\mu D[z]}{\mu f} \right)^n G^2 vf \left(1 + \frac{x[z] vfg}{vf} \right) + G^2 vfg xp[z] + \frac{g \sin[\theta]}{vf (1 + x[z] vfg / vf)} \end{aligned}$$

Numerical Integration

```
 $\Delta PMA[zz\_]$  := NIntegrate[intMA[z], {z, zxe0 + .00001, zz}];
 $\Delta PC[zz\_]$  := NIntegrate[intC[z], {z, zxe0 + .00001, zz}];
 $\Delta PD[zz\_]$  := NIntegrate[intD[z], {z, zxe0 + .00001, zz};
```





HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

Plotting ΔP as a Function of z

```
pPa = Plot[{ $\Delta P_{MA}[z]$ ,  $\Delta P_C[z]$ ,  $\Delta P_D[z]$ }, {z, zxe0, zxe1}, Frame -> True, FrameLabel -> {"z [m]", " $\Delta P_{Total}$  [Pa]", "", ""}, LabelStyle -> (FontSize -> 18),
FrameTicks -> Automatic, FrameTicksStyle -> Black, GridLines -> Automatic, GridLinesStyle -> Directive[Dotted, Gray]]
```

```
ppsi = Plot[{ $\Delta P_{MA}[z] / (1.013 \times 10^5) 14.7$ ,  $\Delta P_C[z] / (1.013 \times 10^5) \times 14.7$ ,  $\Delta P_D[z] / (1.013 \times 10^5) 14.7$ }, {z, zxe0, zxe1}, Frame -> True,
FrameLabel -> {"z [m]", " $\Delta P_{Total}$  [psi]", "", ""}, LabelStyle -> (FontSize -> 18), FrameTicks -> Automatic, FrameTicksStyle -> Black, GridLines -> Automatic,
GridLinesStyle -> Directive[Dotted, Gray]]
```





✖ Cases Using the Homogenous Equilibrium Model

$$\Delta p(z) = \Delta p_{\text{liquid phase}} + \left[\int_{z|_{x_e=0}}^z \left\{ \frac{2}{D_F} c \left(\frac{G D_F}{\mu_f} \right)^{-n} \left(\frac{z(\xi)}{\mu_f} \right)^n G^2 v_f \left(1 + x(\xi) \left(\frac{v_{fg}}{v_f} \right) \right) + G^2 v_{fg} \left(\frac{dx(\xi)}{dz} \right) + \frac{g \sin(\theta)}{v_f (1 + x(\xi) \left(\frac{v_{fg}}{v_f} \right))} \right\} d\xi \right] + \Delta p_{\text{Vapor phase}}$$

```
p = 5 (*bar*);
Cpf = 4312 (*J/kg.K*);
hfg = 2.108 × 106 (*J/kg*);
vf = .0011 (*m3/kg*);
vg = .3748 (*m3/kg*);
μf = 180.1 × 10-6 (*kg/m.s*);
μg = 14.06 × 10-6 (*kg/m.s*);
q = 1.0 × 106 (*W/m2*);
ΔTsub = 30 (*°C*);
g = 9.8 (*m.s-2*);
θ = 90 / 180 π;
DD = .01 (*m*);
L = 1 (*m*);
G = 250 (*kg/m2.s*);
W = G π (DD2 / 4);
A = π DD2 / 4 (*m2*);
```

```
peri = π DD (*m*); DF = 4 A / peri (*m*);
vfg = vg - vf; ReyNum = G DF / μf;
ReyNumg = G DF / μg;
```

Finding $x_e[z]$ and the z location where the thermodynamic quality $x_e=0$ and $x_e=1$

$$x_e[z_-] := - \frac{Cpf \Delta T_{sub}}{hfg} + \frac{\pi DD q}{W hfg} z$$

$$z_{xe0} = \frac{W Cpf \Delta T_{sub}}{\pi DD q}; L1ph = z_{xe0};$$

$x_e[L]$

0.697647

$$z_{xe1} = \frac{hfg W}{\pi DD q} + \frac{Cpf \Delta T_{sub} W}{\pi DD q}; L2ph = z_{xe1};$$


If [$L2ph < L$, $intL = L2ph$, $intL = L$];

```
x[z_] :=
Piecewise[{{0, z < zxe0}, {xe[z], z > zxe0 && z < zxe1},
{Min[xe[L], 1], z > zxe1}}]

x[z_] :=
Piecewise[{{0, z < L1ph}, {xe[z], z > L1ph && z < intL},
{Min[xe[L], 1], z > intL}}]

xp[z_] := x'[z]

Plot[x[z], {z, 0, L + .5 L}, Frame → True,
FrameLabel → {"z [m]", "Quality x"}, GridLines → Automatic,
LabelStyle → {FontSize → 16}, PlotRange → {{0, L}, {0, 1}}]
```






HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

```

 $\mu_{MA}[z\_]$  :=  $\frac{\mu_g \mu_f}{x[z] \mu_f + (1 - x[z]) \mu_g}$  (*kg/m.s*); "McAdams";
 $\mu_C[z\_]$  :=  $x[z] \mu_g + (1 - x[z]) \mu_f$  (*kg/m.s*);
"Cicciotti et al.";
 $\mu_D[z\_]$  :=  $\frac{x[z] v_g \mu_g + (1 - x[z]) v_f \mu_f}{x[z] v_g + (1 - x[z]) v_f}$  (*kg/m.s*); "Duckler";
LogPlot[{ $\mu_{MA}[z]$ ,  $\mu_C[z]$ ,  $\mu_D[z]$ }, {z, 0, 1}, Frame -> True,
FrameLabel -> {"z [m]", " $\mu_{TP}$  [kg/m.s]", "", ""},
LabelStyle -> {FontSize -> 18}, FrameTicks -> Automatic,
FrameTicksStyle -> Black, GridLines -> Automatic,
GridLinesStyle -> Directive[Dotted, Gray]]

```



```

If[ReyNum < 2300, {c = 16, n = 1}]
If[2.3 x 10^3 < ReyNum < 2 x 10^4, {c = .079, n = .25}]
If[ReyNum > 2 x 10^4, {c = .046, n = .2}]
{0.079, 0.25}

```

```

If[ReyNum < 2300, {c = 16, n = 1}]
If[4 x 10^3 < ReyNum < 2 x 10^4, {c = .079, n = .25}]
If[ReyNum > 2 x 10^4, {c = .046, n = .2}]
{0.046, 0.2}

```

$$\Delta p(z) = \Delta p_{\text{liquid phase}} + \left[\int_{z|_{x_e=0}}^z \left\{ \frac{2}{DF} c \left(\frac{GDF}{\mu_f} \right)^{-n} \left(\frac{z(\xi)}{\mu_f} \right)^n G^2 v_f \left(1 + x(\xi) \left(\frac{v_{fg}}{v_f} \right) \right) + G^2 v_{fg} \left(\frac{dx(\xi)}{dz} \right) + \frac{g \sin(\theta)}{v_f (1 + x(\xi) \left(\frac{v_{fg}}{v_f} \right))} \right\} d\xi \right] + \Delta p_{\text{Vapor phase}}$$

```

intMA[z_] :=  $\frac{2}{DF} c \left( \frac{GDF}{\mu_f} \right)^{-n} \left( \frac{\mu_{MA}[z]}{\mu_f} \right)^n G^2 v_f \left( 1 + \frac{x[z] v_{fg}}{v_f} \right) + G^2 v_{fg} xp[z] + \frac{g \sin[\theta]}{v_f (1 + x[z] v_{fg} / v_f)}$ ;
intC[z_] :=  $\frac{2}{DF} c \left( \frac{GDF}{\mu_f} \right)^{-n} \left( \frac{\mu_C[z]}{\mu_f} \right)^n G^2 v_f \left( 1 + \frac{x[z] v_{fg}}{v_f} \right) + G^2 v_{fg} xp[z] + \frac{g \sin[\theta]}{v_f (1 + x[z] v_{fg} / v_f)}$ ;
intD[z_] :=  $\frac{2}{DF} c \left( \frac{GDF}{\mu_f} \right)^{-n} \left( \frac{\mu_D[z]}{\mu_f} \right)^n G^2 v_f \left( 1 + \frac{x[z] v_{fg}}{v_f} \right) + G^2 v_{fg} xp[z] + \frac{g \sin[\theta]}{v_f (1 + x[z] v_{fg} / v_f)}$ ;

```

```


APMA[zz_] := NIntegrate[intMA[z], {z, zxe0 + .00001, zz}] +  $\frac{2 c \text{ReyNum}^{-n} v_f G^2 L_{lph}}{DF}$  +  $\frac{2 c \text{ReyNum}^{-n} v_f G^2 (L - \text{intL})}{DF}$ ;
APC[zz_] := NIntegrate[intC[z], {z, zxe0 + .00001, zz}] +  $\frac{2 c \text{ReyNum}^{-n} v_f G^2 L_{lph}}{DF}$  +  $\frac{2 c \text{ReyNum}^{-n} v_f G^2 (L - \text{intL})}{DF}$ ;
APD[zz_] := NIntegrate[intD[z], {z, zxe0 + .00001, zz}] +  $\frac{2 c \text{ReyNum}^{-n} v_f G^2 L_{lph}}{DF}$  +  $\frac{2 c \text{ReyNum}^{-n} v_f G^2 (L - \text{intL})}{DF}$ ;

```





HYDRODYNAMICS AND PRESSURE DROP IN TWO-PHASE EVAPORATING AND CONDENSING FLOWS

```
Plot[{ $\Delta P_{MA}[z]$ ,  $\Delta P_C[z]$ ,  $\Delta P_D[z]$ }, {z, 0, L}, Frame  $\rightarrow$  True,
FrameLabel  $\rightarrow$  {"z [m]", " $\Delta P_{Total}$  [Pa]", "", ""},
LabelStyle  $\rightarrow$  (FontSize  $\rightarrow$  18), FrameTicks  $\rightarrow$  Automatic,
FrameTicksStyle  $\rightarrow$  Black, GridLines  $\rightarrow$  Automatic,
GridLinesStyle  $\rightarrow$  Directive[Dotted, Gray], PlotRange  $\rightarrow$  All]
```



```
Plot[{ $\Delta P_{MA}[z] / (1.013 \times 10^5) \times 14.7$ ,  $\Delta P_C[z] / (1.013 \times 10^5) \times 14.7$ ,
 $\Delta P_D[z] / (1.013 \times 10^5) \times 14.7$ }, {z, 0, L}, Frame  $\rightarrow$  True,
FrameLabel  $\rightarrow$  {"z [m]", " $\Delta P_{Total}$  [psi]", "", ""},
LabelStyle  $\rightarrow$  (FontSize  $\rightarrow$  18), FrameTicks  $\rightarrow$  Automatic,
FrameTicksStyle  $\rightarrow$  Black, GridLines  $\rightarrow$  Automatic,
GridLinesStyle  $\rightarrow$  Directive[Dotted, Gray], PlotRange  $\rightarrow$  All]
```





Pressure Drop in Separated Flows

Slip Flow Model

TWO-PHASE SEPARATED FLOWS-SLIP FLOW MODEL



Features

- Allows For differences in phase velocities
- Intended for annular and stratified flows.
- Separate Analyses of individual phases


Assumptions

- Different but Uniform phase velocities

$$u_g \neq u_f \quad S \neq 1$$

- Uniform pressure over entire flow area

$$p_g = p_f = p$$





TWO-PHASE SEPARATED FLOWS-SLIP FLOW MODEL

Basic Relations

$$u_g = \frac{Q_g}{A_g} \cdot \frac{\rho_g}{\rho_g} = \frac{W_g}{\rho_g A_g} \quad \text{but } A_g/A = \alpha \Rightarrow A_g = \alpha A$$

$$\Rightarrow u_g = \frac{W_g}{\rho_g \alpha A} = \frac{x W}{\rho_g \alpha A}$$

$$\frac{W_g}{W} = x \Rightarrow W_g = x W$$

$$\frac{W}{A} = G$$

$$u_g = \frac{x G}{\alpha \rho_g}$$

$$u_f = \frac{(1-x) G}{(1-\alpha) \rho_f} \quad \text{from } u_f = \frac{Q_f}{A_f}$$

$$\bar{p} = \alpha \rho_g + (1-\alpha) \rho_f \quad \text{However } S \neq 1$$

In the Homogenous equilibrium model, we derived

$$\frac{1}{\bar{\rho}} = \bar{v} = x v_g + (1-x) v_f \quad \leftarrow \text{This was based on } S=1$$

$$\Rightarrow \frac{1}{\bar{\rho}} \neq \bar{v} \quad \text{because } S \neq 1$$

Void fraction becomes an unknown in this formulation



TWO-PHASE SEPARATED FLOWS-SLIP FLOW MODEL

Conservation Laws / Mass conservation

• Transport Theorem

$$\bigcirc \frac{\partial}{\partial t} \int_V \rho \, dv + \int_S \rho \vec{u}_r \cdot d\vec{s} = 0$$

◆ Vapor phase


$$\frac{\partial}{\partial t} (\rho_g A_g) + \frac{\partial}{\partial z} (\rho_g u_g A_g) - W'_{fg} = 0$$

$$\Rightarrow \frac{\partial}{\partial t} (\rho_g \alpha A) + \frac{\partial}{\partial z} (x W) - W'_{fg} = 0$$

◆ Liquid phase

$$\frac{\partial}{\partial t} (\rho_f A_f) + \frac{\partial}{\partial z} (\rho_f A_f u_f) + W'_{fg} = 0$$

$$\Rightarrow \frac{\partial}{\partial t} [\rho_f (1-\alpha) A] + \frac{\partial}{\partial z} [(1-x) W] + W'_{fg} = 0$$



TWO-PHASE SEPARATED FLOWS-SLIP FLOW MODEL



◆ Combining the two phases

$$\frac{\partial}{\partial t} \left[\underbrace{\rho_g \alpha A + \rho_f (1-\alpha) A}_{\bar{\rho} A} \right] + \frac{\partial}{\partial z} (W) = 0$$

$$\Rightarrow \frac{\partial}{\partial t} [\bar{\rho} A] + \frac{\partial}{\partial z} (W) = 0 \quad \text{W's cancelled when combining both phases}$$



TWO-PHASE SEPARATED FLOWS-SLIP FLOW MODEL

◆ Vapor phase

$$\partial_t (\rho_g u_g \alpha A) + \partial_z (\rho_g u_g^2 \alpha A) - W'_{fg} u_i = -\alpha A \partial_z P - \mathcal{C}_{Fg} P_{Fg} - \mathcal{C}_i P_i - \rho_g \alpha A \sin \theta$$

◆ Liquid phase

$$\begin{aligned} \partial_t (\rho_f u_f (1-\alpha) A) + \partial_z (\rho_f u_f^2 (1-\alpha) A) + W'_{fg} u_i \\ = -(1-\alpha) A \partial_z P - \mathcal{C}_{Ff} P_{Ff} + \mathcal{C}_i P_i - \rho_f (1-\alpha) A \sin \theta \end{aligned}$$

◆ Combined

$$\begin{aligned} \partial_t (W) + \partial_z \left\{ \left[\rho_g \alpha u_g^2 + \rho_f (1-\alpha) u_f^2 \right] A \right\} \\ = -A \partial_z P - \mathcal{C}_{Fg} P_{Fg} - \mathcal{C}_{Ff} P_{Ff} - [\rho_g \alpha + \rho_f (1-\alpha)] A \sin \theta \end{aligned}$$

Interfacial terms cancel out -



TWO-PHASE SEPARATED FLOWS-SLIP FLOW MODEL

Mass, Energy & Momentum

◆ Mass $\partial_t(\bar{\rho}A) + \partial_z(W) = 0$

◆ Momentum $\partial_t(W) + \partial_z \left(\left[\rho_g \alpha \left(\frac{xW}{\rho_g \alpha A} \right)^2 + \rho_f (1-\alpha) \left(\frac{(1-x)W}{\rho_f (1-\alpha) A} \right)^2 \right] A \right)$
 $= -\partial_z p - \mathcal{C}_{Fg} P_{Fg} - \mathcal{C}_{Ff} P_{Ff} - \bar{\rho} A g \sin \theta$

Conservation of Energy.

Internal energy, heat, and work.

$$\partial_t [\rho_g h_g^o \alpha A + \rho_f h_f^o (1-\alpha) A] + \partial_z [x W h_g^o + (1-x) W h_f^o] = (q_g'' P_{Hg} + q_f'' P_{Hf})$$

$$+ [q_g''' \alpha A + q_f''' (1-\alpha) A] + \partial_t(pA)$$

Here

$$h_g^o = h_g + u_g^2/2 + g z \sin \theta \quad h_f^o = h_f + \frac{u_f^2}{2} + g z \sin \theta$$



TWO-PHASE SEPARATED FLOWS-SLIP FLOW MODEL

Steady State and other simplifications.

Steady state $\partial/\partial t () = 0 \Rightarrow$ Continuity yields

$$\Rightarrow \partial_z W = 0 \Rightarrow W = \text{const} = GA \quad \text{With } A \text{ const}$$

$$\Rightarrow G = \text{constant}$$

Neglecting kinetic and potential energy

$$h_k^o \rightarrow h_k \quad k = f, g \quad x = x_e$$

Momentum

$$G^2 \frac{d}{dz} \left(\frac{x^2}{\rho_g \alpha} + \frac{(1-x)^2}{\rho_f (1-\alpha)} \right) = -\frac{dp}{dz} - \frac{2F_g P_{Fg}}{A} - \frac{2F_f P_{Ff}}{A} - \bar{\rho} g \sin \theta$$



TWO-PHASE SEPARATED FLOWS-SLIP FLOW MODEL

Energy

$$W \frac{dh}{dz} = q'' P_H$$

$$h = h_f + x_e h_{fg}$$

$$q'' P_H = q''_g P_{Hg} + q''_f P_{Hf}$$

$$\Rightarrow \frac{dx_e}{dz} = \frac{q'' P_H}{W h_{fg}}$$

$$\Rightarrow x_e(z) = x_{e,i} + \frac{P_H}{W h_{fg}} \int_0^z q'' d\zeta$$

Energy yielded quality as a function of z

We know $x[z]$

\Rightarrow In the momentum equation, α and $C_F P_F$ are the unknowns



TWO-PHASE SEPARATED FLOWS-SLIP FLOW MODEL

As in the previous formulation,

$$-\frac{dp}{dz} = -\frac{dp}{dz}|_F + -\frac{dp}{dz}|_{AC} + -\frac{dp}{dz}|_G$$

❖ Frictional

$$-\frac{dp}{dz}|_F = \frac{\tau_F P_F}{A} = \left(\frac{z}{D_F} f_{fo} v_f G^2 \right) \frac{z}{f_{fo}} \text{ Liquid based only.}$$

$$-\frac{dp}{dz}|_G = \bar{p} g \sin \theta = (\alpha \rho_g + (1-\alpha) \rho_f) g \sin \theta$$

$$-\frac{dp}{dz}|_A = G^2 \frac{d}{dz} \left(\frac{x^2 v_g}{\alpha} + \frac{(1-x) v_f}{(1-\alpha)} \right)$$

TWO-PHASE SEPARATED FLOWS-SLIP FLOW MODEL



Gravity

$$-\frac{dp}{dz} \Big|_G = \bar{\rho} g \sin \theta = [\alpha \rho_g + (1-\alpha) \rho_f] g \sin \theta$$

Acceleration

$$-\frac{dp}{dz} = G^2 \left[\frac{d}{dz} \left(\frac{\chi^2 v_g}{\alpha} + \frac{(1-\chi)^2 v_f}{1-\alpha} \right) \right]$$

When flashing is negligible

$$\Rightarrow \chi \neq f(p)$$

TWO-PHASE SEPARATED FLOWS-SLIP FLOW MODEL




Martinelli-Nelson Method for Separated Flow Pressure Drop

$$\Delta P = \sum \int \left(-\frac{dp}{dz} \right)_i = \Delta p_F + \Delta p_A + \Delta p_G$$


$$\Delta P_A = \left[G^2 v_f \right] r_2$$

$$\Delta P_F = \left[\frac{2L}{D_F} f_{fo} G^2 v_f \right] r_3$$

$$\Delta p_G = \left[\frac{gL \sin \theta}{v_f} \right] r_4$$



- As $x_L \nearrow$, $\Delta p_A \nearrow \nearrow$
- As $p \searrow$, x_L has stronger effect
- $p_{crit} = 220.55 \text{ bar}$





- As $x_L \nearrow$, $\Delta p_F \nearrow \nearrow$, especially at low pressures

1. Martinelli - Nelson (1948) $\left\{ \begin{array}{l} \text{High } p \\ \text{Horizontal flow: no } r_4 \\ \text{Steam - water} \end{array} \right.$

$$r_2, r_3, r_4 = f(p_{in}, x_{e,L})$$



TWO-PHASE SEPARATED FLOWS-SLIP FLOW MODEL





PRESSURE DROP IN SEPARATED FLOWS

Pressure Drop in Separated Flows Lockhart-Martinelli's Approach for Adiabatic Flows



PRESSURE DROP IN SEPARATED FLOWS

Separated Flow Pressure Drop Calculations

Lockhart - Martinelli Method.

Assumptions

- Low pressure
- Horizontal
- Adiabatic (air-water)
- $-\left[\frac{dp}{dz}\right]_F$ only

Basis for development of new correlations by many authors

$$-\left[\frac{dp}{dz}\right]_F = -\left[\frac{dp}{dz}\right]_f \phi_f^2 = -\left[\frac{dp}{dz}\right]_g \phi_g^2$$

$$-\left(\frac{dp}{dz}\right)_f = \frac{2 f_f G^2 (1-x)^2 v_f}{D_F} \quad ; \quad f_f = \frac{A}{Re_f^n} \quad ; \quad Re_f = \frac{G(1-x) D_F}{\mu_f}$$

$$-\left(\frac{dp}{dz}\right)_g = \frac{2 f_g G^2 x^2 v_g}{D_F} \quad ; \quad f_g = \frac{A}{Re_g^n} \quad ; \quad Re_g = \frac{G x D_F}{\mu_g}$$

	A	n
Laminar	16	1
Turbulent	.046	.2



PRESSURE DROP IN SEPARATED FLOWS

○ Lockhart-Martinelli Parameter

$$X^2 = \frac{-\frac{dp}{dz}|_f}{-\frac{dp}{dz}|_g} \quad \begin{array}{l} \text{Laminar} \quad A=16 \quad n=1 \\ \text{Turbulent} \quad A=.046 \quad n=.2 \end{array}$$

○ Sequence of Calculation

- Given p, x, G, D_F

- Calculate $-\frac{dp}{dz}|_f$; $\frac{dp}{dz}|_g$
- Calculate X
- Determine C from table

$$\phi_f^2 = 1 + \frac{E}{X} + \frac{1}{X^2}$$

$$\begin{aligned} \bullet -\frac{dp}{dz}|_F &= -\frac{dp}{dz}|_f \cdot \phi_f^2 \\ \bullet \Delta p_F &= \int_0^{L_{TP}} \left(-\frac{dp}{dz} \right)_F dz \end{aligned}$$

Flow state Liquid-gas

	C
Turbulent - Turbulent	20
Laminar - Turbulent	12
Turbulent - Laminar	10
Laminar - Laminar	5



PRESSURE DROP IN SEPARATED FLOWS

Example Problems

"Fluid is FC-72"

```

p = 2 (*bar*);
Cpf = 1136 (*J/kg.K*);
hfg = 87272 (*J/kg*);
vf = .0006515 (*m³/kg*);
vg = .0387 (*m³/kg*);
μf = 349.0 × 10-6 (*kg/m.s*);
μg = 12.3 × 10-6 (*kg/m.s*);
σ = .0062 (*N/m*);
q = 4.0 × 104 (*W/m²*);
ΔTsub = 0 (*°C*);
g = 9.8 (*m.s-2*);
θ = 0 / 180 π;
DD = .005 (*m*);
L = .25 (*m*);
G = 250 (*kg/m².s*);
W = G π (DD² / 4);
A = π DD² / 4 (*m²*);
peri = π DD (*m*);
DF = 4 A / peri (*m*);
vfg = vg - vf;
ReyNum = G DF / μf;
ReyNumg = G DF / μg;

```

Quality as a Function of z, $x_e(z)$

```

xe[z_] := - Cpf ΔTsub / hfg + π DD q / W hfg z
xe0 = xe[0]
xel = xe[L]

0.
0.36667

zxe0 = W Cpf ΔTsub / π DD q; L1ph = zxe0;
zxe1 = hfg W / π DD q + Cpf ΔTsub W / π DD q; L2ph = zxe1;
If[L2ph < L, intL = L2ph, intL = L];

```


Void Fraction and Quality (Zivi, 1964)

```

α[z_] := (1 + (1 - xe[z]) (vf/vg)2/3)-1

Plot[{xe[z], α[z]}, {z, zxe0 + .00001, intL},
Frame → True,
FrameLabel → {"z [m]", "xe, α",
"α-Orange, xe-Blue", ""},
LabelStyle → {FontSize → 18},
FrameTicks → Automatic, FrameTicksStyle → Black,
GridLines → Automatic,
GridLinesStyle → Directive[Dotted, Gray],
PlotRange → {{0, L}, {0, 1}}]

```



Friction Factors on the liquid and gas sides

```

ff[z_] :=
Piecewise[{{16 (G (1 - xe[z]) DD / μf)-1, (G (1 - xe[z]) DD / μf) < 2000},
{.079 (G (1 - xe[z]) DD / μf)-0.25, 2000 < (G (1 - xe[z]) DD / μf) < 20000},
{.046 (G (1 - xe[z]) DD / μf)-0.2, (G (1 - xe[z]) DD / μf) > 20000}}]

fg[z_] :=
Piecewise[{{16 (G (xe[z]) DD / μg)-1, (G (xe[z]) DD / μg) < 2000},
{.079 (G (xe[z]) DD / μg)-0.25, 2000 < (G (xe[z]) DD / μg) < 20000},
{.046 (G (xe[z]) DD / μg)-0.2, (G (xe[z]) DD / μg) > 20000}}]

```

Constant C

```

CC[z_] :=
Piecewise[{{5, (G (1 - xe[z]) DD / μf) < 2000 && (G (xe[z]) DD / μg) < 2000},
{12, (G (1 - xe[z]) DD / μf) < 2000 && 2000 < (G (xe[z]) DD / μg)},
{10, 2000 < (G (1 - xe[z]) DD / μf) && (G (xe[z]) DD / μg) < 2000},
{20, 2000 < (G (1 - xe[z]) DD / μf) && 2000 < (G (xe[z]) DD / μg)}}]

```




PRESSURE DROP IN SEPARATED FLOWS

Frictional, Acceleration and Gravitational Pressure Gradients

$\text{dpdzF}[z_]:=$

$$\frac{1}{DD} 2 G^2 \text{vf ff}[z] (1 - \text{xe}[z])^2$$

$$\left(1 + \frac{\text{CC}[z]}{\sqrt{\frac{\text{vf ff}[z] (1 - \text{xe}[z])^2}{\text{vg fg}[z] \text{xe}[z]^2}}} + \frac{\text{vg fg}[z] \text{xe}[z]^2}{\text{vf ff}[z] (1 - \text{xe}[z])^2} \right)$$

$$\text{dpdzA}[z_]:= G^2 \text{vf} \left(\frac{(\text{xe}[z])^2 \text{vg}}{\alpha[z] \text{vf}} + \frac{(1 - (\text{xe}[z]))^2}{(1 - \alpha[z])} - 1 \right)$$

$$\text{dpdzG}[z_]:= \left(\frac{\alpha[z]}{\text{vg}} + \frac{(1 - \alpha[z])}{\text{vf}} \right) g \sin[\theta]$$


Integrated Pressure Drop, $\Delta P = \int_0^L -(\text{dp} / \text{dz}) \, dz$

$\Delta PF[z_]:= \text{NIntegrate}[\text{dpdzF}[zz], \{zz, \text{zxe0}, z\}]$

$\Delta PA[z_]:= G^2 \text{vf} \left(\frac{(\text{xe}[z])^2 \text{vg}}{\alpha[z] \text{vf}} + \frac{(1 - (\text{xe}[z]))^2}{(1 - \alpha[z])} - 1 \right)$

$\Delta PG[z_]:= \text{NIntegrate}[\text{dpdzG}[zz], \{zz, \text{zxe0}, z\}]$

```
Plot[{ $\Delta PF[z]$ ,  $\Delta PA[z]$ ,  $\Delta PG[z]$ ,  $\Delta PF[z] + \Delta PA[z] + \Delta PG[z]$ },
 {z,  $\text{zxe0} + .00001$ ,  $\text{intL}$ }, Frame  $\rightarrow$  True,
 FrameLabel  $\rightarrow$  {"z [m]", " $\Delta P_F$ ,  $\Delta P_A$ ,  $\Delta P_G$ ,  $\Delta P_T$  [Pa]",
 " $\Delta P_F$ -Blue,  $\Delta P_A$ -Orange,  $\Delta P_G$ -Green,  $\Delta P_T$ -Red", ""},
 LabelStyle  $\rightarrow$  (FontSize  $\rightarrow$  18), FrameTicks  $\rightarrow$  Automatic,
 FrameTicksStyle  $\rightarrow$  Black, GridLines  $\rightarrow$  Automatic,
 GridLinesStyle  $\rightarrow$  Directive[Dotted, Gray], PlotRange  $\rightarrow$  All]
```






PRESSURE DROP IN SEPARATED FLOWS

Pressure Drop in Separated Flows SFM with Mudawar's Universal Evaporating Flows Correlation



PRESSURE DROP IN SEPARATED FLOWS





PRESSURE DROP IN SEPARATED FLOWS

PURDUE
UNIVERSITY

More Recent Efforts

- Most published correlations for two-phase pressure drop recommended for relatively large tube diameters. Popular and successful correlations include those of Friedel (1979) and Müller-Steinhagen & Heck (1986)
- Small diameters crucial to reducing TCS mass in space systems and ensuring gravity independent evaporation and condensation
- New efforts undertaken at Purdue University Boiling and Two-Phase Flow Lab (PU-BTPFL) to **derive universal correlations for small diameters (less than ~ 6 mm)** by amassing published data for many fluids and over very broad ranges of operating conditions for:
 - Adiabatic and condensing flows
 - Evaporating flows
- The Purdue correlations are being tested against newly obtained microgravity data



October 2013 Short Course
NASA Glenn Research Center

Course: Two-Phase Flow

Prof. Issam Mudawar



PRESSURE DROP IN SEPARATED FLOWS



Limitations of Two-Phase Flow and Heat Transfer Correlations

One-phase: forced convection in a pipe:

$$Nu = 0.023 Re^{0.8} Pr^{1/3}$$

$$\Pi_1 = f(\Pi_2, \Pi_3)$$

$$\left\{ \begin{array}{l} Re > 10,000 \\ 0.6 < Pr < 160 \end{array} \right.$$

Very powerful correlation applicable to many fluids over very broad range of flow conditions

Two-phase: steam-water critical heat flux in a pipe:

$$\frac{q_m''}{G h_{fg}} = f\left(\frac{\rho_f}{\rho_g}, \frac{G^2 L}{\sigma \rho_f}, \frac{c_{p,f} \Delta T_{sub}}{h_{fg}}, \frac{L}{D}, \frac{G}{\rho_f \sqrt{g D}}, \dots\right)$$

$$\Pi_1 = f(\Pi_2, \Pi_3, \Pi_4, \Pi_5, \Pi_6, \dots)$$

$$\left\{ \begin{array}{l} \Pi_{2,min} < \Pi_2 < \Pi_{2,max} \\ \Pi_{3,min} < \Pi_3 < \Pi_{3,max} \\ \Pi_{4,min} < \Pi_4 < \Pi_{4,max} \\ \Pi_{5,min} < \Pi_5 < \Pi_{5,max} \\ \Pi_{6,min} < \Pi_6 < \Pi_{6,max} \end{array} \right.$$

Simultaneously satisfying ranges for several parameters greatly limits overall usefulness of correlation ... **Correlations cannot be extended with confidence to other fluids and/or beyond their validity range!**





October 2013 Short Course
NASA Glenn Research Center

Course: Two-Phase Flow

Prof. Issam Mudawar



PRESSURE DROP IN SEPARATED FLOWS

 Dimensionless Groups Employed by Various Investigators in Prediction of Two-Phase Pressure Gradient		
Liquid- or gas-only Reynolds number:	$Re_{fo} = \frac{G D_h}{\mu_f}, \quad Re_{go} = \frac{G D_h}{\mu_g}$	$\frac{\text{Inertia}}{\text{Viscous force}}$
Superficial liquid or gas Reynolds number:	$Re_f = \frac{G(1-x)D_h}{\mu_f}, \quad Re_g = \frac{Gx D_h}{\mu_g}$	$\frac{\text{Inertia}}{\text{Viscous force}}$
Density ratio:	$\frac{\rho_f}{\rho_g}$	$\frac{\text{Liquid density}}{\text{Vapor density}}$
Weber Number:	$We = \frac{G^2 D_h}{\rho_f \sigma}$	$\frac{\text{Inertia}}{\text{Surface tension force}}$
Capillary number:	$Ca = \frac{\mu_f G}{\rho_f \sigma} \left(= \frac{We}{Re_{fo}} \right)$	$\frac{\text{Viscous force}}{\text{Surface tension force}}$
Liquid- or gas-only Suratman number:	$Su_{fo} = \frac{\rho_f \sigma D_h}{\mu_f^2} \left(= \frac{Re_{fo}^2}{We} \right), \quad Su_{go} = \frac{\rho_g \sigma D_h}{\mu_g^2} \left(= \frac{Re_{go}^2}{We} \right)$	-
Froude number:	$Fr = \frac{G^2}{g D_h \rho_f^2}$	$\frac{\text{Inertia}}{\text{Body force}}$
Bond Number:	$Bd = \frac{g(\rho_f - \rho_g) D_h^2}{\sigma}$	$\frac{\text{Bouyancy force}}{\text{Surface tension force}}$
Confinement Number:	$N_{conf} = \sqrt{\frac{\sigma}{g(\rho_f - \rho_g) D_h^2}} \left(= \sqrt{\frac{1}{Bd}} \right)$	$\sqrt{\frac{\text{Surface tension force}}{\text{Body force}}}$
Galileo Number:	$Ga = \frac{\rho_f g(\rho_f - \rho_g) D_h^3}{\mu_f^2}$	-
 October 2013 Short Course NASA Glenn Research Center		
Course: Two-Phase Flow		Prof. Issam Mudawar



PRESSURE DROP IN SEPARATED FLOWS

PURDUE
UNIVERSITY

Pressure Drop in Saturated Two-Phase Flow Region

Two-phase pressure drop:

$$\Delta p_{tp} = \Delta p_F + \Delta p_G + \Delta p_A$$

Accelerational pressure drop:

$$\left(-\frac{dp}{dz}\right)_A = G^2 \frac{d}{dz} \left[\frac{v_g x^2}{\alpha} + \frac{v_f (1-x)^2}{(1-\alpha)} \right] \quad \text{where} \quad \alpha = \left[1 + \left(\frac{1-x_e}{x_e} \right) \left(\frac{v_f}{v_g} \right)^{2/3} \right]^{-1} \quad \begin{cases} \Delta p_A > 0 & \text{for boiling flows} \\ \Delta p_A < 0 & \text{for condensing flows} \end{cases}$$

(Zivi, 1964)

Gravitational pressure drop:

$$\left(-\frac{dp}{dz}\right)_G = [\alpha \rho_g + (1-\alpha) \rho_f] g \sin \phi$$

Frictional pressure drop:

Homogeneous Equilibrium Model (HEM)

$$\left(-\frac{dp}{dz}\right)_f = \frac{2 f_{tp} \bar{\rho} u^2}{D_h} = \frac{2 f_{tp} v_f G^2}{D_h} \left(1 + x \frac{v_g}{v_f} \right)$$

$$\begin{aligned} f_{tp} &= 16 Re_{tp}^{-1} & \text{for } Re_{tp} < 2,000 \\ f_{tp} &= 0.079 Re_{tp}^{-0.25} & \text{for } 2,000 \leq Re_{tp} < 20,000 \\ f_{tp} &= 0.046 Re_{tp}^{-0.2} & \text{for } Re_{tp} \geq 20,000 \end{aligned}$$

$$\text{where } Re_{tp} = \frac{G D_h}{\mu_{tp}}$$

Separated Flow Model (SFM)

$$\left(\frac{dp}{dz}\right)_f = \left(\frac{dp}{dz}\right)_f \phi_f^2 \quad \text{where} \quad \phi_f^2 = 1 + \frac{C}{X^2} + \frac{1}{X^4}, \quad X^2 = \frac{(dp/dz)_f}{(dp/dz)_g}$$

$$\left(-\frac{dp}{dz}\right)_f = \frac{2 f_f v_f G^2 (1-x)^2}{D_h}, \quad \left(-\frac{dp}{dz}\right)_g = \frac{2 f_g v_g G^2 x^2}{D_h}$$

$$\begin{aligned} f_k &= 16 Re_k^{-1} & \text{for } Re_k < 2,000 \\ f_k &= 0.079 Re_k^{-0.25} & \text{for } 2,000 \leq Re_k < 20,000 \\ f_k &= 0.046 Re_k^{-0.2} & \text{for } Re_k \geq 20,000 \end{aligned} \quad \text{where } k = f \text{ or } g$$

Two-phase pressure drop:

$$\Delta p_{tp} = \int_0^{L_{tp}} \left[\left(-\frac{dp}{dz}\right)_f - \left(-\frac{dp}{dz}\right)_G - \left(-\frac{dp}{dz}\right)_A \right] dz$$



October 2013 Short Course
NASA Glenn Research Center

Course: Two-Phase Flow

Prof. Issam Mudawar



PRESSURE DROP IN SEPARATED FLOWS

PURDUE
UNIVERSITY

New PU-BTPFL Two-Phase Frictional Pressure Drop Correlation for Evaporating Flow in Small Diameter Tubes

**Consolidated database:
2378 boiling pressure drop data points
from 16 sources**

- Working fluids:
R12, R134a, R22, R245fa, R410A, FC-72,
ammonia, CO₂, water
- Hydraulic diameter:
 $0.349 < D_h < 5.35$ mm
- Mass velocity:
 $33 < G < 2738$ kg/m²s
- Liquid-only Reynolds number:
 $156 < Re_{l0} < 28,010$
- Superficial liquid Reynolds number:
 $0 < Re_l < 16,020$
- Superficial vapor (or gas) Reynolds number:
 $0 < Re_g < 199,500$
- Flow quality:
 $0 < x < 1$
- Reduced pressure:
 $0.005 < P_r < 0.78$

$$\left(\frac{dp}{dz}\right)_F = \left(\frac{dp}{dz}\right)_f \phi_f^2 \quad \text{where} \quad \phi_f^2 = 1 + \frac{C}{X} + \frac{1}{X^2}, \quad X^2 = \frac{(dp/dz)_f}{(dp/dz)_g}$$

$$-\left(\frac{dp}{dz}\right)_f = \frac{2f_f v_f G^2 (1-x)^2}{D_h}, \quad -\left(\frac{dp}{dz}\right)_g = \frac{2f_g v_g G^2 x^2}{D_h}$$

$$f_k = 16 Re_k^{-1} \quad \text{for} \quad Re_k < 2,000$$

$$f_k = 0.079 Re_k^{-0.25} \quad \text{for} \quad 2,000 \leq Re_k < 20,000$$

$$f_k = 0.046 Re_k^{-0.2} \quad \text{for} \quad Re_k \geq 20,000 \quad \text{where } k = f \text{ or } g$$

for laminar flow in rectangular channel,

$$f_k Re_k = 24(1 - 1.3553\beta + 1.9467\beta^2 - 1.7012\beta^3 + 0.9564\beta^4 - 0.2537\beta^5)$$

$$Re_f = \frac{G(1-x)D_h}{\mu_f}, \quad Re_g = \frac{Gx D_h}{\mu_g}, \quad Re_{fv} = \frac{G D_h}{\mu_f}, \quad Su_{go} = \frac{\rho_g \sigma D_h}{\mu_g^2}$$

$$C = C_{non-boiling} \left[1 + 530 We_{fo}^{0.52} \left(Bo \frac{P_H}{P_F} \right)^{1.09} \right] \quad \text{for} \quad Re_f < 2000$$

$$C = C_{non-boiling} \left[1 + 60 We_{fo}^{0.32} \left(Bo \frac{P_H}{P_F} \right)^{0.78} \right] \quad \text{for} \quad Re_f \geq 2000$$

$$\text{where} \quad We_{fo} = \frac{G^2 D_h}{\rho_f \sigma}, \quad Bo = \frac{q_H'}{G h_{fg}}$$

q_H' effective heat flux averaged over heated perimeter of channel

P_H heated perimeter of channel

P_F wetted perimeter of channel



October 2013 Short Course
NASA Glenn Research Center

Course: Two-Phase Flow

Prof. Issam Mudawar



PRESSURE DROP IN SEPARATED FLOWS

Example Problems


"Fluid is FC-72"

```
p = 2 (*bar*);
Cpf = 1136 (*J/kg.K*);
hfg = 87272 (*J/kg*);
vf = .0006515 (*m³/kg*);
vg = .0387 (*m³/kg*);
mf = 349.0 × 10-6 (*kg/m.s*);
mg = 12.3 × 10-6 (*kg/m.s*);
σ = .0062 (*N/m*);
q = 4.0 × 104 (*W/m²*);
ΔTsub = 0 (*°C*);
g = 9.8 (*m.s-2*);
θ = 0 / 180 π;
DD = .005 (*m*);
L = .25 (*m*);
G = 250 (*kg/m².s*);
W = G π (DD² / 4);
A = π DD² / 4 (*m²*); peri = π DD (*m*);
DF = 4 A / peri (*m*);
vfg = vg - vf;
ReyNum = G DF / mf;
ReyNumg = G DF / mg;
BoNum = q / (G hfg);
WeNumf0 = (G² DF vf) / (Cpf ΔTsub);
xe[z_] := - (Cpf ΔTsub / hfg) + (π DD q / (W hfg)) z;
xe0 = xe[0];
xel = xe[L];
zxe0 = (W Cpf ΔTsub / (π DD q)); L1ph = zxe0;
zxe1 = (hfg W / (π DD q) + (Cpf ΔTsub W / (π DD q))); L2ph = zxe1;
If[L2ph < L, intL = L2ph, intL = L];
```

Void Fraction and Quality (Zivi, 1964)

```
α[z_] := (1 + (1 - xe[z]) (vf / vg)2/3)-1;
PF[z_] := π DD (1 - α[z]); PF[z_] := π DD;
PH = π DD
0.015708
```

```
Plot[{xe[z], α[z]}, {z, zxe0 + .00001, intL}, Frame → True,
FrameLabel → {"z [m]", "xe, α", "α-Orange, xe-Blue", ""},
LabelStyle → {FontSize → 18}, FrameTicks → Automatic,
FrameTicksStyle → Black, GridLines → Automatic,
GridLinesStyle → Directive[Dotted, Gray],
PlotRange → {{0, L}, {0, 1}}]
```



Friction Factors on the Liquid and Gas Sides

```
ff[z_] :=
Piecewise[{{16 (G (1 - xe[z]) DD)-1, (G (1 - xe[z]) DD) < 2000},
{.079 (G (1 - xe[z]) DD)-0.25, 2000 < (G (1 - xe[z]) DD) < 20000},
{.046 (G (1 - xe[z]) DD)-0.2, (G (1 - xe[z]) DD) > 20000}}];
fg[z_] :=
Piecewise[{{16 (G (xe[z]) DD)-1, (G (xe[z]) DD) < 2000},
{.079 (G (xe[z]) DD)-0.25, 2000 < (G (xe[z]) DD) < 20000},
{.046 (G (xe[z]) DD)-0.2, (G (xe[z]) DD) > 20000}}];
```

Constant $C_{\text{Non-Boiling}}$

```
CC[z_] :=
Piecewise[{{5, (G (1 - xe[z]) DD) / (mf DD) < 2000 && (G (xe[z]) DD) / (mg DD) < 2000},
{12, (G (1 - xe[z]) DD) / (mf DD) < 2000 && 2000 < (G (xe[z]) DD) / (mg DD)},
{10, 2000 < (G (1 - xe[z]) DD) / (mf DD) && (G (xe[z]) DD) / (mg DD) < 2000},
{20, 2000 < (G (1 - xe[z]) DD) / (mf DD) && 2000 < (G (xe[z]) DD) / (mg DD)}}];
```

Constant C_{Boiling}

```
CCM[z_] :=
Piecewise[
{{CC[z] (1 + 530 WeNumf0.52 (BoNum PH / PF[z])1.09),
(G (1 - xe[z]) DD) / (mf DD) < 2000},
{CC[z] (1 + 60 WeNumf0.32 (BoNum PH / PF[z]).78),
(G (1 - xe[z]) DD) / (mf DD) > 2000}]]
```

Frictional, Acceleration and Gravitational Pressure Gradients

$\text{dpdzF}[z] :=$

$$\frac{1}{DD} 2 G^2 vf ff[z] (1 - xe[z])^2$$

$$\left(1 + \frac{CCM[z]}{\sqrt{\frac{vf ff[z] (1 - xe[z])^2}{vg fg[z] xe[z]^2}}} + \frac{vg fg[z] xe[z]^2}{vf ff[z] (1 - xe[z])^2} \right)$$

$$\text{dpdzA}[z] := G^2 vf \left(\frac{(xe[z])^2 vg}{\alpha[z] vf} + \frac{(1 - (xe[z]))^2}{(1 - \alpha[z])} - 1 \right)$$

$$\text{dpdzG}[z] := \left(\frac{\alpha[z]}{vg} + \frac{(1 - \alpha[z])}{vf} \right) g \sin[\theta]$$

Integrated Pressure Drop, $\Delta P = \int_0^L -(\text{dp}/\text{dz}) dz$

```
ΔPF[z_] := NIntegrate[dpdzF[zz], {zz, xe0, z}]
```

```
ΔPA[z_] := G² vf ( (xe[z])² vg / (α[z] vf) + (1 - (xe[z]))² / (1 - α[z]) - 1 )
```

```
ΔPG[z_] := NIntegrate[dpdzG[zz], {zz, zxe0, z}]
```



PRESSURE DROP IN SEPARATED FLOWS

```
Plot[{ $\Delta P_F[z]$ ,  $\Delta P_A[z]$ ,  $\Delta P_G[z]$ ,  $\Delta P_F[z] + \Delta P_A[z] + \Delta P_G[z]$ },
{z, zxe0 + .00001, intL}, Frame  $\rightarrow$  True,
FrameLabel  $\rightarrow$  {"z [m]", " $\Delta P_F$ ,  $\Delta P_A$ ,  $\Delta P_G$ ,  $\Delta P_T$  [Pa]",
" $\Delta P_F$ -Blue,  $\Delta P_A$ -Orange,  $\Delta P_G$ -Green,  $\Delta P_T$ -Red", ""},
LabelStyle  $\rightarrow$  (FontSize  $\rightarrow$  18), FrameTicks  $\rightarrow$  Automatic,
FrameTicksStyle  $\rightarrow$  Black, GridLines  $\rightarrow$  Automatic,
GridLinesStyle  $\rightarrow$  Directive[Dotted, Gray], PlotRange  $\rightarrow$  All]
```

